


00007777000

www.sinotruk-parts-store.com



S26	Low range signal switch
S27L	Cab left lock signal switch
S27R	Cab right lock signal switch
S29	Air filter clogging alarm switch
R11	Air dryer
D7	Diode
F5	Reversing buzzer

E38\E39	Left and right front fog lamps
E52\E53	Left and right brake lights
E9/L,R	Left and right rear fog lights
E14/L,R	Left and right reversing lights
Y8	Center follow-up steering solenoid valve
S15	Reverse signal switch

①	Battery negative
④①	Grounding point on the left side of the cab
④②	Grounding point in the middle of the cab
④③	Grounding point on the right side of the cab

A	Switch signal input
B	Front fog lights
C	Rear fog lamps
D	Reversing lights
E	Brake light

标记	数量	文件号	签字	日期