


0000LLZL6ZV



E1	Left rear position light
E2	Right rear position light
E3a	Left front lighting high beam
E3b	Left front lighting low beam
E4a	Right front lighting high beam
E4b	Right front lighting low beam
E5	Left front position light
E6	Right front position light

E25L,R	Left and right side marker lights of tractor
E30	Ashtray light
E40	Left auxiliary high beam
E41	Right auxiliary high beam

①	Battery negative
④①	Ground point on the left side of the cab
④②	Grounding point in the middle of the cab
④③	Grounding point on the right side of the cab

A	Position light
B	Headlamps and auxiliary high beams