

Electrical Junction Box	
1	Battery negative
41	Ground point on the left side of the cab
42	Grounding point in the middle of the cab
43	Grounding point on the right side of the cab